


Conex | Bänninger

# >B< MaxiPro

Join the Press Revolution

## Air Conditioning and Refrigeration




### Installing a >B< MaxiPro female flare connector to a male flare connector.

Make the flare connection prior to pressing the >B< MaxiPro joint. If this is not possible care must be taken to prevent rotational forces being applied to the pressed joint.

Align the centres of both flares and tighten the flares by hand (see Fig. 1 for copper flare and Fig. 2 for stainless flare with copper washer). Then fully tighten using spanner and torque wrench (see Fig. 3) to the torque values set out in the table. **Do not over tighten.**

Apply Conex Bänninger lubricating oil\*

Apply Conex Bänninger lubricating oil to the inner surface of the flare.




**Do not** apply lubricating oil to the flare nut threads to avoid overtightening.

Fig. 1 Copper flare.

Apply Conex Bänninger lubricating oil\*

Apply Conex Bänninger lubricating oil to the inner surface of the flare and copper washer.



**Do not** apply lubricating oil to the flare nut threads to avoid overtightening.

Fig. 2 Stainless flare with copper washer.




Fig. 3 Tighten joint using torque wrench.

\*Note: A compatible refrigerant oil may be used if Conex Bänninger lubricating oil is not available.

#### Flares Tightening Torque

Size	N m	ft lbf
1/4"	14-18	11-13
3/8"	33-42	25-31
1/2"	50-62	37-45
5/8"	63-77	47-56
3/4"	90-110	67-81

Do not over tighten

# Conex | Bänninger

Conex | Bänninger  
>B< Press

Conex | Bänninger  
>B< Press Gas

Conex | Bänninger  
>B< Press Solar

Conex | Bänninger  
>B< Press XL

Conex | Bänninger  
>B< Press Carbon

Conex | Bänninger  
>B< Press Inox

Conex | Bänninger  
>B< MaxiPro

Conex | Bänninger  
>B< ACR

**K65®**

Conex | Bänninger  
>B< Push

Conex | Bänninger  
>B< Flex

Conex | Bänninger  
>B< Oyster

Conex | Bänninger  
>B< Sonic

Conex | Bänninger  
Triflow Solder Ring

Conex | Bänninger  
Delcop End Feed

Conex | Bänninger  
Delbraze

Conex | Bänninger  
Medical Gas

Conex | Bänninger  
Valves

Conex | Bänninger  
Conex Compression

Conex | Bänninger  
Series 3000

Conex | Bänninger  
Series 4000

Conex | Bänninger  
Series 5000

Conex | Bänninger  
Series 8000

Conex | Bänninger  
OEM



IBP Group LLC. 24 Cathedral Place, Suite 400, St Augustine, FL 32084

Tel: 904-217-4970 | Fax: 904-460-2603 | Email: SalesUSA@IBPGroup.com | Website: www.conexbanninger.com

#### Global Headquarters:

Conex Universal Limited. Global House, 95 Vantage Point, The Pensnett Estate, Kingswinford, West Midlands, DY6 7FT, UNITED KINGDOM.

Tel: +44 (0) 121 557 2831 | Fax: +44 (0) 121 557 0185 | Email: salesuk@ibpgroup.com | Website: www.conexbanninger.com

The content of this publication is for general information only. It is the user's responsibility to determine suitability of any product for the purpose intended and reference should be made to our Technical Department if clarification is required. In the interests of technical development we reserve the right to change specification, design and materials without notice.

Conex Bänninger products are approved by numerous Standards Authorities and Certification Bodies. IBP trademarks are registered in numerous countries.

More information available online at: [www.conexbanninger.com](http://www.conexbanninger.com).